

# **SNAP18 MODULE**

# ASSEMBLY OF MODULE INTO DRILL BODY

# Explanation individual parts


# 2

- 1 Blade
- **2** SNAP18 Module (referred as "module" in the following instructions)
- 3 Fixing screw M3 (with loosening lock)

#### **Caution:**

Replace the fixing screw after each module dissasembly (blade exchange).

# Mounting



Insert the module with the mounted blade (1) into the drill body – the cutting edge faces the drill tip, and the screw clearance (2) is aligned with the screw position. Fully tighten the fastening screw (3) until it bottoms out and secure it with 1.5 Nm.

#### Mounted modul



#### Check:

The screw (3) must not protrude; otherwise, the module is incorrectly installed.

### Recommended assembly tool



#### Option 1:

Torque screwdriver, fixed setting 1.5 Nm



#### Option 2:

PrecisionBit for hexagon, 1/4 inch C 6.3, 1.5 mm

